
An Adaptive Cross-Correlation Algorithm for Extended-Scene Shack-Hartmann Wavefront Sensing

Erkin Sidick

Joseph J. Green, Catherine M. Ohara, and David C. Redding

***Jet Propulsion Laboratory
California Institute of Technology***

SRS 2007 in Vancouver, BC, Canada, June 18-20, 2007. Paper JTUA





National Aeronautics and
Space Administration


Jet Propulsion Laboratory
California Institute of Technology
Pasadena, California

Principle of Conventional SH-WFS

- A Shack-Hartmann sensor places a lenslet array at a plane conjugate to the WF error source
- Each sub-aperture lenslet samples the WF in the corresponding patch of the WF
- When observing a star, the image is an array of spots, each of which is a sub-aperture PSF
 - Δx is proportional to local wavefront tilt
 - Wavefront-sensing \rightarrow Finding Δx for all sub-images
 - Use centroiding (center-of-mass) method to find Δx




Extended-Scene S-H WFS



(a)





(b)



(c)

- The Shack-Hartmann Camera produces images as the convolution of the conventional image (limited by a tight field stop) with a regular grid of subaperture PSFs, as above
- Each subaperture is much blurrier than the main image, as its diffraction limit is defined by the subaperture, not the full aperture



- Subaperture image shown at right at full size (64x64)
- ACC algorithm finds the central 32x32 box, and then identifies the multi-pixel shift of the features in the inner 16x16 cell with respect to a reference subaperture
- The subaperture-to-subaperture cell shifts give a measure of subaperture tilt





National Aeronautics and
Space Administration
Jet Propulsion Laboratory
California Institute of Technology
Pasadena, California

Point-Source (Star) versus Extended-Scene

- Following images were measured at JPL SH-WFS Testbed
 - Can be used with both point-source and extended-scene
 - Each spot-image is replaced by a sub-image in extended-scene SH-WFS
 - Local wavefront distortion causes a sub-image to shift from ideal position
 - SH camera provides large capture range WFS&C



Autofocus Testbed



National
Shack-Hartmann


Jet Propulsion Laboratory
California Institute of Technology
Pasadena, California

Adaptive Cross-Correlation (ACC) Algorithm — How it Works

- Property of Fourier-transform:
 - Shift in time-domain \leftrightarrow Linear-phase in frequency-domain
 - In Fourier optics, $t \rightarrow (x, v)$ and $f \rightarrow (u, v)$
- Fourier-transform pair—Shown as one-dimensional for simplicity:

$$s(x) \leftrightarrow \hat{s}(u)$$

$$s(x - \Delta x) \leftrightarrow \hat{s}(u) e^{-j2\pi\Delta x u}$$





ACC Algorithm — How it Works (con.)

- In JPL testbed, only those cells marked with red-circle are used:
 - $r(x)$ = reference cell
 - $s(x)$ = test cells

- In ideal case:


$$r(x) \leftrightarrow \hat{r}(u)$$

$$s(x) = r(x - \Delta x) \leftrightarrow \hat{r}(u) e^{-j2\pi\Delta x u}$$



ACC Algorithm — How it Works (con.)

- Black square = usable sub-image (cell)
- Real world is very different from the ideal case:



ACC Algorithm — How it Works (con.)

- Following illustration was made in one-dimension only. In reality, everything is 2-dimensional: $(x,y) \leftrightarrow (u,v)$

- In real world:


$$r(x) \leftrightarrow \hat{r}(u)$$

$$s(x) \neq r(x - \Delta x)$$

$$s(x) \leftrightarrow \hat{s}(u)$$


$$\hat{c}(u) = \hat{r} * (u) \hat{s}(u) = |\hat{c}(u)| e^{j2\pi\varphi(u)}$$

$$\varphi(u) = \Delta x u + \varphi'(u)$$




Linear phase

Cross-correlation function




National Aeronautics and
Sack-Hartmann WFS
Jet Propulsion Laboratory
California Institute of Technology
Pasadena, California



ACC Algorithm — How it Works (con.)



- Advantages of using smaller dimensions for $r(x,y)$ & $s(x,y)$:
 - Avoids wrap-around error when performing sub-image multi-pixels shifting
 - Makes the ACC calculations much faster
 - Increases the WFS dynamic range
- To shift $S(x,y)$ by $(-\Delta x, -\Delta y)$:
 - Obtain $S(u,v)$ by FFT $\rightarrow S(u,v)\exp[-j2\pi(-\Delta xu - \Delta yv)] \rightarrow$ (by IFFT) $S(x+\Delta x, y+\Delta y)$




ACC Flow-Chart



32 x 32 Pixels Test Cells to be Analyzed

- Obtained 8 SH images with different integration time
- Used different cells for $r(x,y)$ & $s(x,y)$
- Red-square corresponds to a 16x16 pixels area


- Variations of IQM's with itegration time:
 - MSE = Mean-Squared Error
 - MFI = Modified Fisher-Information



$$MSE = \sum_{x,y} |g_i(x,y) - \bar{g}_i(x,y)|^2$$



$$\Psi_i(x,y) = g_i(x,y) / 4095$$

$$MFI = 4 \times \sum_{x,y} [\nabla a_i(x,y)]^* \cdot \nabla a_i(x,y), \quad a_i(x,y) = \sqrt{\Psi_i(x,y)}$$






Speed versus Tolerance

- Shifted $s(x,y)$ by known amount Δx , and determined the relative offset between $r(x,y)$ and $s(x,y)$ with ACC
- Used different cells for $r(x,y)$ & $s(x,y)$







Examples: Point-Source Spot Image Analyzed with ACC


DM Poke Patterns



Offset Diagrams






Deformable-Mirror (DM)




National Aeronautics and
Space Administration
Sack-Hartmann WFS
Jet Propulsion Laboratory
California Institute of Technology
Pasadena, California

Extended Scene versus Point-Source


- Same poke patterns are used in both cases, but the measurement are done on different dates.
- There are some differences in light path and actuator registration for point-source and extended scene, which is partially responsible for difference in OPD results.



RMS = 50, PV = 299.5nm




RMS = 54.7, PV = 327.4nm




National Aeronautics and
Space Administration
Jet Propulsion Laboratory
California Institute of Technology
Pasadena, California

OPD Map Measured with Extended Scene

DM Poke Pattern




Reconstructed OPD Map



OPD is in nm


Active Window




National Aeronautics and
Space Administration
Sack-Hartmann WFS
Jet Propulsion Laboratory
California Institute of Technology
Pasadena, California

Example of Extended-Scene WFS&C


- There are 78 actuators inside the active window, but only 50 eigen-modes were used in this experiment.




RMS = 54.7, PV = 327.4nm




RMS = 40.6, PV = 295.2nm




RMS = 38.5, PV = 261.9nm



RMS = 37.5, PV = 292nm



RMS = 34, PV = 277.8nm



National Aeronautics and
Space Administration
Sack-Hartmann WFS
Jet Propulsion Laboratory
California Institute of Technology
Pasadena, California

Summary

- Extended-scene SH sensor is useful when point-source is not available but SH-WFS is needed
- ACC requires only about 4 image-shifting iterations to achieve 0.01 pixel accuracy
- ACC is insensitive to both background light and noise—much more robust than centroiding
- **Acknowledgement**
 - We thank Rhonda Morgan at JPL for her assistance with the S-H testbed